

Disguise An Ignition Interlock

MAKE YOUR OWN INCOGNITO IID COVER

Gas Station Cup Cover



1. You will need a Big Gulp sized cup and lid from a gas station.



2. Remove the bottom part of the cup so that it can slide over your device like a sleeve.



3. Once the main part of the cup is over the device, make a slit and an opening for the cord in the part of the cup that you removed. Secure it back on the bottom of the cup and around the cord with tape.



4. Make a small hole in the cup lid so that the mouthpiece can attach to the device. Then, attach the lid and the mouthpiece like a straw.

Coffee Drive Through Cup Cover



1. You will need a Trenta size coffee cup, lid, and tissue paper the color of a coffee drink.

2. Remove the bottom part of the cup so that it can slide over your device like a sleeve.

3. Using the bottom of the cup that you removed, you will cut an opening for the cord and then tape it back on.



4. You will then need to cut your tissue paper to line the inside of your cup and the inside of the lid. Secure it on the inside seam with tape and also on the edges of the lid.



5. Make a small hole in the cup lid so that the mouthpiece can attach to the device like a straw.

Dollar Store Plastic Mug Cover



1. This cover uses an oversized plastic travel mug from the Dollar Store. Other tools include a drill and utility knife. Use care with tools to prevent injury.



2. Drill holes through the two plastic layers that make up the bottom of the mug. Then, use the utility knife to cut out each layer, opening up the entire bottom of the mug. It can then be slipped over the IID like a sleeve. Secure the bottom with study packing tape or duct tape.



3. Pop off the vent slider portion of the lid. Then place the lid on your mug.



4. In the lid opening, place the mouthpiece into the IID so that it is operational. It will look like a straw at the top of the mug.

Candy Box Cover



1. This cover uses an empty candy box from candy purchased at a grocery store. You will also need strong tape (like clear moving tape).



2. You will open both ends of the box and slide it over the device, like a sleeve. You will then secure the bottom of the device and the top of the cable attachment to the bottom of the box using tape.



3. When you need to use the device, open the top of the box and insert the mouthpiece. This disguise allows for the device to be hidden when your car is parked and off.



Intoxalock®